

Thinkgeek Spycam Car Key Fob Camera



[To record video]

1. Connect camera to USB cable to charge for about 3 hours. Then disconnect from USB cable.
2. Begin with the camera turned off, the LED will not be illuminated at all. (If LED is illuminated, go directly to step #4).
3. Press and hold the On/Off button for about 2 seconds and release, the LED will illuminate.
4. Press and hold the Video/Camera button for about 2 seconds and release. The LED will blink quickly 3 times and then turn off. When LED turns off, this means you are now recording video.
5. When you are finished recording video, press the Video/Camera button and release. The LED will illuminate, meaning video recording has ended. Then press and hold the On/Off button for about 4-5 seconds and release to turn the camera off.
6. Connect the camera to USB cable to download the video files.

[To take photos]

1. Begin with the camera turned off, the LED will not be illuminated at all. (If LED is illuminated, go directly to step #3).
2. Press and hold the On/Off button for about 2 seconds and release, the LED will illuminate.
3. Press the Video/Camera button once and release. The LED will turn off and then on again, indicating you've taken the photo. When finished press and hold the On/Off button for about 4-5 seconds and release to turn the camera off.
4. Connect camera to USB cable to download the photo files.

[To set the time stamp]

1. Create a text file, and save in the camera root directory as "TAG.txt"
2. The text file will contain the starting date and time you desire, written as:

[date]
2010/07/01
12:00:00