

**Setup and Cancel:**  
These buttons are  
not used with this bulb

Turns bulb Off or On

**Flash:** Pauses on a color  
for about 1 sec and then  
abruptly changes to a  
different color

**Strobe:** Pauses on a color  
for about 5 seconds and  
then abruptly changes to  
a different color

These 15 buttons + W will  
select a specific color and  
remain on that color until  
another button is pressed  
(if user presses the Yellow  
button the bulb will give  
a yellow color light until a  
different color is pressed)

**Fade:** Will gradually  
transition from one  
color to another color  
(quickly)

**Smooth:** Will gradually  
transition from one  
color to another color  
(very slowly)

Brightest

These 4 buttons control  
the brightness level  
of the bulb

Dimmest



Please note that this remote must be pointed directly at the bulb  
at a distance of 5 feet or less for best performance.

The remote uses one CR2025 Lithium Battery (widely available  
at most stores)