

## ThinkGeek Bluetooth Watch with Caller ID Display

\*Important: Charge the Bluetooth Watch for 8 hours before using it for the first time.\*

The Bluetooth Watch will:

- Alert you when your phone rings with a discreet vibrating sensation and display the caller's name and/or number on the OLED display
- The watch will work up to 10 meters, or 32 feet, away from your phone
- Notify you of received SMS messages by vibrating and displaying the text alert icon
- Allow you to mute the phone's ringer or reject a call by simply pushing a button on the watch
- Allow you to review your phone's address book on the watch OLED display

### \*Key Functions\*

The bottom button on the watch is the MENU key, the top button is the SELECT key

Press the MENU key to bring up the watch's MENU

To scroll through the menu options press the MENU key until the function you choose is highlighted and then press the SELECT key

To turn off the menu scroll through all the icons

### \*Accepting a Call

-To accept an incoming call press the MENU key

### \*Rejecting a Call

-To reject an incoming call press the SELECT key

### \*Set Up

To connect your phone to the open the watch's menu and select the second icon (( )), then open your phone's Bluetooth menu and follow your phone's instructions

The default watch PIN is 0000

The Bluetooth icon will indicate that your phone is connected to the watch when the icon is highlighted, if the icon is not highlighted your phone is not connected to it

To end the Bluetooth connection press the select key on the Bluetooth icon

### \*Menu Icons

(Bluetooth icon)

The Bluetooth icon will indicate if the Bluetooth is turned off or on, if the icon is highlighted Bluetooth is on, if the icon is not highlighted Bluetooth is off

(pairing icon)

The pairing icon will show the status of pairing your Bluetooth watch to your phone, a dot in the center of the icon will indicate that the watch is in pairing mode, if no dot appears then the watch is not in pairing mode

(connection status icon)

The connection status icon will indicate if a call is connected, if a call is connected the icon will appear as normal, if no call is connected the icon will show a pair of scissors (disconnection cue icon) The disconnection cue icon

(SMS/MMS cue icon)

The SMS/MMS icon will alert you to incoming SMS/MMS messages

(address book icon)

The address book icon will allow you to read your phone's address book from the Bluetooth watch OLED display, to set up this option highlight the icon with the MENU key and then press the select key, the watch will show as "updating" after which you should be able to review your address book on the watch

(battery icon)

The battery icon will show when your Bluetooth watch's battery is low, when it shows it's time to recharge

