

Setup and Cancel:
These buttons are
not used with this bulb

Turns bulb Off or On

Flash: Pauses on a color
for about 1 sec and then
abruptly changes to a
different color

Strobe: Pauses on a color
for about 5 seconds and
then abruptly changes to
a different color

These 15 buttons + W will
select a specific color and
remain on that color until
another button is pressed
(if user presses the Yellow
button the bulb will give
a yellow color light until a
different color is pressed)

Fade: Will gradually
transition from one
color to another color
(quickly)

Smooth: Will gradually
transition from one
color to another color
(very slowly)

Brightest

These 4 buttons control
the brightness level
of the bulb

Dimmest



Please note that this remote must be pointed directly at the bulb
at a distance of 5 feet or less for best performance.

The remote uses one CR2025 Lithium Battery (widely available
at most stores)