


Bluetooth Retro Handset



Instructions:

1. Connect the Bluetooth Retro Handset to the USB cable and plug in. Allow it to charge for about 6-8 hours before the first use.
2. You will need to pair the Bluetooth Retro Handset with your cell phone (Bluetooth pairing is the process of establishing the wireless link between two devices). Refer to your cell phone manual for instructions on how to use the Bluetooth pairing function in your phone.
3. Push and hold the silver button on the Bluetooth Retro Handset. After about 5 seconds, the blue LED Indicator light will illuminate briefly and the Bluetooth Retro Handset will make a short sound. Continue holding the silver button for another 3 or 4 seconds until the blue LED starts to blink rapidly. When the blue LED is blinking rapidly the Bluetooth Retro Handset is in pairing mode.
4. Follow your phone's instruction manual. This normally involves going to a "Setup", "Connect", "Connection" or "Bluetooth" menu **on your cell phone** and then selecting the option to "Look for Devices", "Add a device" or "Discover" to initiate the Bluetooth pairing process.
5. Your cell phone will scan for local Bluetooth devices and should locate the Bluetooth Retro Handset after about 10-20 seconds.
6. When you pair your cellphone with the Bluetooth Retro Handset it will prompt you to enter a PIN number – enter "0000" for this number.
7. At this point you should be able to place a call using your cell phone keypad, phonebook, or voice dial and use the Bluetooth Retro Handset in place of your phone's handset. The Bluetooth Retro Handset should function much like any handsfree headset.
8. To answer an incoming call press the silver button.
9. To turn off the Bluetooth Retro Handset press and hold the silver button for about 3 seconds until you hear a short sound and the blue LED turns off.